INDOOR WALL-MOUNTED SPEAKER
Installation Manual



IP NETWORK INTERCOM SYSTEM

Connection Diagram



Dimensional Drawing (unit: mm)



Installation Diagram

Step 1: Mount the 2 M4 screws horizontally to the wall surface according to the mounting holes and leave a distance of approx. 5 mm as shown in the picture



on the right.	
Step 2: Hook the 2 hoist holes of the unit to the screw heads and tighten the screws so that they are firm and do not wobble. Also visually inspect the installation for correct orientation and any tilt.	

Note:When installing, please ensure the strength of the mounting surface and do not install directly on walls with insufficient strength such as plasterboard; as a last resort, please fully reinforce the mounting position.

Specifications

Name	Indoor Wall-mounted speaker
Power	30W
Impedance	8Ω
Sensitivity	89±3
Frequency Response	200HZ~20KHZ
Color	White/Black
Installation	Wall-mounted
Size	290*117*215mm
Operating Temp/Hum	-10℃～+45℃ / 10%-90% no condensation

Packing List

Plastic expansion sleeve 3pcs(7mm*28)

Half round head phillips screws 3pcs(ST4*35)

Installation manual 1pcs

VI.1B220304